



UMODPC



The Transportation
Coordinator-Automated
Command and Control
Information System
(TC-ACCIS)

612-301-03




TC-ACCIS



- TC-ACCIS is an information management and data communication system used by the U.S. Army (Reserve and Active) to:
 - Plan and execute unit deployments
 - Create & maintain UMD, plan rail movements, prepare convoy requests, vehicle load plans MSLs & other movement documentation
- Principal users are UMOs & UMC/ITO



Distribution & Functional Diagram





TC-ACCIS Information Flow



UMC / ITO

MACOM




TC-ACCIS

COMPASS

JOPES



612-301-03





TC-ACCIS Familiarization




- This lesson is only a brief familiarization to TC-ACCIS functions.
- It is not and should not be considered a TC-ACCIS certification course.
- You or someone in your command should attend formal TC-ACCIS training.



Keyboard



- Standard PC Keyboard





Specialized Key Functions



Enter / Return Key



Specialized Key Functions (Cont)



[F6] Help keys

[F7] Text Help key



Control (Ctrl) Key

Arrow keys



Specialized Key Functions (Cont)



Ctrl-H move left one character

Ctrl-K move up one row



Ctrl-J move down one row

Ctrl-L move right one character




Specialized Key Functions (Cont)



AUEL mode

[F1] insert a row



[F2] delete a row



Specialized Key Functions (Cont)



[F3] key next page [F4] key previous page



F-7, F-8, F-9, & F10 - Special use keys - Use as directed in the instruction line



UMO Basic TC-ACCIS Tasks



- UMOs should be able to accomplish the following TC-ACCIS tasks:
 - Sign on to the system
 - Locate the Automated Unit Equipment List Data (AUEL)
 - Update and maintain the AUEL
 - Create the Deployment Equipment List (DEL)





UMO Basic TC-ACCIS Tasks (Cont)



- UMOs should be able to: (Cont)
 - Create documentation for Highway Movements
 - Submit a Request for Transportation
 - Create a Unit Rail Load List
 - Produce TC-ACCIS reports



Using The TC-ACCIS System



Logging On



- Logging onto the System is based on local procedures
- Different locations may have different requirements
- You will need a password obtained from the local system administrator or other designated authority

DD/MM/YY

TC-ACCIS Main Menu

FICIF001

1- Equipment List Processing

2-ITO Equipment List Processing

3-Shipping Planning

4-Transportation Requests

5-Highway Movement Planning

6-Load Planning

7-Transportation Documentation

8-Passenger Manifest

9-Electronic Mail

A-User Utilities

E-System Logoff

Enter Selection:



TC ACCIS Version: 5.0.112

UMODPC

612-901-03

DD/MM/YY

Equipment List Processing

FICEUF078

1 - Equipment List Administration

2 - Equipment List Data

3 - View Equipment List

4 - Equipment List Reports

5 -What if Analysis

6 - Archive Directory

E - Exit to TC ACCIS Main Menu

Enter Selection: 2





Maintain AUEL (Cont)



- Enter Type Data Code:
 - D - Active Components
 - S - Reserve Components

DD/MM/YY

Equipment List Processing

FICEUF078

Press [ESC] to Accept, [CTRL-C] to Abort

DD/MM/YY

Select Type Data Code

FICEUF074

Type Data Code: S

Enter the TDC or Press [F6] for Help

Enter Selection: 2



Maintain Ring Menu



- Select appropriate option from the Maintain Ring Menu:

1-Header

5-Ammo/Hazardous

2-Vehicles

6-Exit

3-SpecHdling

4-Actual Weight

MAINTAIN: 1-Header 2-Vehicle 3-SpecHdng 4-Actual Weight...

Maximize Full Screen Print Help Quit Master entries on Equipment List

DD/MM/YY

FICEUFO12

Equipment List Data

list sorted by

UIC

Exercise

* C Sun VI Model Description

LIN/Index EchULN DMS A/H *

DETAIL FOR

Ser#

Bumper

Owner

L

SqFt

Empty Wt

TEC

WCC

WI

TPC

W

CuFt

ActWt

STONS

SHC

CCCC

Ov

H

CuLd

MaxWt

MTONS

TCC

Vehicle Remarks

MAINTAIN: ... 5 - Ammo/Hazard E-Exit

Maintain Ammunition/Hazardous Data for Vehicles/Containers

DD/MM/YY

Equipment List Data

FICEUFO12

UIC

list sorted by

Exercise

* C Sun VI Model Description

LIN/Index

EchULN

DMS A/H *

DETAIL FOR

Ser#

Bumper

Owner

L

SqFt

Empty Wt

TEC

WCC

WI

TPC

W

CuFt

ActWt

STONS

SHC

CCCI

Ov

H

CuLd

MaxWt

MTONS

TCC

Vehicle Remarks

UMODPC

612-301-03



Maintain Vehicle



- Select option "2-Vehicle" from Maintenance Ring menu

MAINTAIN: 1-Header 2-Vehicle 3-SpecHdling 4-Actual Weight...

Maintain Vehicle Entries on Equipment List

DD/MM/YY

Equipment List Data

FICEUFO12

UIC

list sorted by

Exercise

* C Sun VI Model Description

LIN/Index

EchULN

DMS A/H *

DETAIL FOR

Ser#

Bumper

Owner

L

SqFt

Empty Wt

TEC

WCC

WI

TPC

W

CuFt

ActWt

STONS

SHC

CCCI

Ov

H

CuLd

MaxWt

MTONS

TCC

Vehicle Remarks

UMODPC

612-301-03

EQUIPMENT: 1-Maintain 2-Copy 3-Sort 4-Query E-Exit

Maintain Vehicles or Special Handling Equipment

DD/MM/YY

FICEUFO12

Equipment List Data

UIC

list sorted by

Exercise

* C Sun VI Model Description

LIN/Index

EchULN DMS A/H *

DETAIL FOR

Ser#

Bumper

Owner

L

SqFt

Empty Wt

TEC

WCC

WI

TPC

W

CuFt

ActWt

STONS

SHC

CCCI

Ov

H

CuLd

MaxWt

MTONS

TCC

Vehicle Remarks

UMODPC

612-301-03



Maintain Vehicle Equipment List



- Select "1-Maintain" on the Equipment ring menu
- Press Enter key
- Next Screen opens up

EQUIPMENT: 1-Maintain 2-Copy 3-Sort 4-Query E-Exit

Maintain Vehicles or Special Handling Equipment

DD/MM/YY

FICEUFO12

Equipment List Data

UIC

list sorted by

Exercise

* C Sun VI Model Description

LIN/Index

EchULN DMS A/H *

DETAIL FOR

Ser#

Bumper

Owner

L

SqFt

Empty Wt

TEC

WCC

WI

TPC

W

CuFt

ActWt

STONS

SHC

CCCI

Ov

H

CuLd

MaxWt

MTONS

TCC

Vehicle Remarks

UMODPC

612-301-03

EQUIPMENT: 1-Maintain 2-Copy 3-Sort 4-Query E-Exit

Press [ESC] to accept [F1] to add [F2] to delete or [F9] for detail section

DD/MM/YY Equipment List Data FICEUFO12

FULL list sorted by SHIPMENT NUMBER

UIC WAD5A0

Exercise D

* C	Sun	VI	Model	Description	LIN/Index	Ech	ULN	D	M	S	A/H	*			
			D0001	V	M113	CARRIER PERSONNEL FTRAC	D12087	01	00		D	K	Y	N	*
Y			D0002	V	M2	INFANTRY FIGHTING VEHICLE	J87150	02	00		D	K	Y	N	*
Y			D0003	V	M2	INFANTRY FIGHTING VEHICLE	J87150	02	00		D	K	Y	N	*
			D0004	V	M2	INFANTRY FIGHTING VEHICLE	J87150	02	00		D	K	Y	N	*
			D0005	V	M2	INFANTRY FIGHTING VEHICLE	J87150	02	00		D	K	Y	N	*

DETAIL FOR D0001

Ser#	Bumper	N.O.H.	Tra/Bmp#	I	Owner
L 192	SqFt 142	Empty Wt 18940	TEC	WCC 876	WM TPC VO
W 106	CuFt 1166	ActWt 18940	STONS 9.5	SHC 9	COCI A2DB Ov Y
H 99	CuLd 0	MaxWt 21440	MTONS 30	TCC Z	

Vehicle Remarks

VEHICLE LOAD DATA FOR D0001

Load Description	LINIndex	SUN	Load#	Qty	COR
------------------	----------	-----	-------	-----	-----

LIN Index: Press [F6] for Help



Equipment List Data Screen



- This screen is divided into three sections:
 - Section 1: Equipment List Data
 - Section 2: Detail
 - Section 3: Vehicle Load Data

Section 1

EQUIPMENT: 1-Maintain 2-Copy 3-Sort 4-Query E-Exit

Press [ESC] to accept [F1] to add [F2] to delete or [F9] for detail section

DD/MM/YY Equipment List Data FICEUFO12

----- FULL list sorted by SHIPMENT NUMBER -----

UIC WAD5A0 Exercise D

* C	Sun	VI	Model	Description	LIN/Index	EchULN	D	M	S	A/H	*
			D0001 V	M113	CARRIER PERSONNEL FTRAC	012087 01	00		D	K	Y N *
Y			D0002 V	M2	INFANTRY FIGHTING VEHICLE	J87150 02	00		D	K	Y N *
Y			D0003 V	M2	INFANTRY FIGHTING VEHICLE	J87150 02	00		D	K	Y N *
			D0004 V	M2	INFANTRY FIGHTING VEHICLE	J87150 02	00		D	K	Y N *
			D0005 V	M2	INFANTRY FIGHTING VEHICLE	J87150 02	00		D	K	Y N *

DETAIL FOR D0001

Ser#	Bumper	N.O.H.	Tra/Bmp#	Owner
L 192	SqFt 142	Empty Wt 18900	TEC	CCC 876
W 108	CuFt 1168	Active Wt 21440	5.5 TONS	COCC 9
H 99	CuLd 0	Max Vt 21440	5.5 TONS	CCC Z

Vehicle Remarks

----- VEHICLE LOAD DATA FOR D0001 -----

Load Description	LIN/Index	SUN	Load#	Qty	COR
LIN Index: Press [F6] for Help					

UMODPC 612-301-03

Section 2

Section 3



Add a Vehicle



- Select option [F1] to add
 - Blank line appears with Lin/Index highlighted by the cursor

EQUIPMENT: 1-Maintain 2-Copy 3-Sort 4-Query E-Exit

Press [ESC] to accept [F1] to add [F2] to delete or [F9] for detail section

DD/MM/YY

Equipment List Data

FICEUFO12

FULL list sorted by SHIPMENT NUMBER

UIC WAD5A0

Exercise D

* C	Sun	VI	Model	Description	LIN/Index	EchULN	D	M	S	A/H	*
Y	D0002	V	M213	INFANTRY FIGHTING VEHICLE	J87150 02	00	D	K	Y	N	*
Y	D0002	V	M2	INFANTRY FIGHTING VEHICLE	J87150 02	00	D	K	Y	N	*
y	D0003	V	M2	INFANTRY FIGHTING VEHICLE	J87150 02	00	D	K	Y	N	*
	D0004	V	M2	INFANTRY FIGHTING VEHICLE	J87150 02	00	D	K	Y	N	*

DETAIL FOR D0001

Ser#	Bumper	Tra/Bmp#	/	Owner
L 192 SqFt 142	Empty Wt 18940	TEC	WCC 876	WM TPC vo
W 106 CuFt 1166	ActWt 18940	STONS 9.5	SHC 9	CCCC A2DB Ov Y
H 99 CuLd 0	MaxWt 21440	MTONS 30	TCC Z	

Vehicle Remarks

VEHICLE LOAD DATA FOR D0001

Load Description	LIN/Index	SUN	Load#	Qty	COO
------------------	-----------	-----	-------	-----	-----

Line Item Number (LIN): Press [F6] for Help

UMODPC

612-301-03



Add a Vehicle (Cont)



- Enter LIN number (X40009 02)
 - Press Enter key
- TC-ACCIS adds vehicle and information pertaining to that vehicle
 - You will be prompted to complete the Echelon, MPOE and A/H columns

Note: A vehicle cannot be added to the AUEL without a LIN/Index, but other equipment can

EQUIPMENT: 1-Maintain 2-Copy 3-Sort 4-Query E-Exit

Press [ESC] to accept [F1] to add [F2] to delete or [F9] for detail section

DD/MM/YY

Equipment List Data

FICEUFO12

----- FULL list sorted by SHIPMENT NUMBER -----

UIC WAD5A0

Exercise D

* C	Sun	VI	Model	Description	LIN/Index	EchULN	D	M	S	A/H	*
		D0030	V	M35A2	TRK CARGO 2-1/2-TON	X40009 02	00				
		D0001	V	M113	CARRIER PERSONNEL FTRAC	D12087 01	00				
	Y	D0002	V	M2	INFANTRY FIGHTING VEHICLE	J87150 02	00				
	Y	D0003	V	M2	INFANTRY FIGHTING VEHICLE	J87150 02	00				
		D0004	V	M2	INFANTRY FIGHTING VEHICLE	J87150 02	00				
		D0005	V	M2	INFANTRY FIGHTING VEHICLE	J87150 02	00				

----- DETAIL FOR D0030 -----

Ser#	Bumper	Tra/Bmp#	/	Owner
L 285 SqFt 177 Empty Wt 13180	TEC	WCC 867	WM	TPC vo
W 96 CuFt 1193 ActWt 13180	STONS	8.6 SHC 9	CCCI	R2DB Ov N
H 81 CuLd 0 MaxWt 18180	MTONS	30 TCC z		

Vehicle Remarks

----- VEHICLE LOAD DATA FOR D0030 -----

Load Description	LIN/Index	SUN	Load#	Qty	COR
------------------	-----------	-----	-------	-----	-----

Line Item Number (LIN): Press [F6] for Help

UMODPC

612-301-03



Delete a Vehicle



- Select option [F2] to delete
 - Delete Equipment window screen appears

EQUIPMENT: 1-Maintain 2-Copy 3-Sort 4-Query E-Exit

Pres

DD/

UIC

* C

Y

Y

Y

Ser

L

W

H

Veh

Loa

I IN

[ESC] Accept [CTRL-C] Abort [CTRL-J] Row dn [CTRL-K] Row Up
[F3] Page dn [F4] Page Up [F10] Select All [SPACEBAR] Deselect

DD/MM/YY

Delete Equipment

FICEUF198

X Sun

Model

Description

LIN/Index

EchULN

D0001

M113

Carrier Personnel FTRAC

D12087 07

00

D0002

M2

Infantry Fighting Vehicle

J87150 02

00

D0003

M2

Infantry Fighting Vehicle

J87150 02

00

D0004

M2

Infantry Fighting Vehicle

J87150 02

00

D0005

M2

Infantry Fighting Vehicle

J87150 02

00

D0006

M2

Infantry Fighting Vehicle

J87150 02

00

D0007

M2

Infantry Fighting Vehicle

J87150 02

00

D0008

M2

Infantry Fighting Vehicle

J87150 02

00

D0009

M2

Infantry Fighting Vehicle

J87150 02

00

Press X to Select equipment to DELETE

UMODPC

612-301-03



Modifying Data in TC-ACCIS



Modify Vehicle Detail



- Highlight vehicle to be modified in Section 1 (D0001) and Press the [F9] key
 - Cursor moves to Section 2
 - Only system-highlighted areas may be modified
 - Message line at bottom of screen provides guidance for field entries
- Press Escape [Esc] to finish

EQUIPMENT: 1-Maintain 2-Copy 3-Sort 4-Query E-Exit

Press [ESC] to accept [F1] to add [F2] to delete or [F9] for detail section

DD/MM/YY Equipment List Data FICEUFO12

FULL list sorted by SHIPMENT NUMBER

UIC WAD5A0

Exercise D

* C	Sun	VI	Model	Description	LIN/Index	Ech	U/LN	D	M	S	A/H	*		
Y		D0001	V	M113	CARRIER PERSONNEL FTRAC	D12087	01	00	00	D	K	Y	N	*
Y		D0002	V	M2	INFANTRY FIGHTING VEHICLE	J87150	02	00		D	K	Y	N	*
Y		D0003	V	M2	INFANTRY FIGHTING VEHICLE	J87150	02	00		D	K	Y	N	*
		D0004	V	M2	INFANTRY FIGHTING VEHICLE	J87150	02	00		D	K	Y	N	*
		D0005	V	M2	INFANTRY FIGHTING VEHICLE	J87150	02	00		D	K	Y	N	*

DETAIL FOR D0001

Serial# 11

Bumper N.O.H.

Tra/Bmp# /

Owner

L	192	SqFt	142	Empty Wt	18940	TEC	WCC	878	WM	TPC	vo
W	106	CuFt	1166	ActWt	18940	STONS	9.5	SHC	9	CCC	A2DB
H	99	CuLd	0	MaxWt	21440	MTONS	30	TCC	Z	Ov	Y

Vehicle Remarks

VEHICLE LOAD DATA FOR D0001

Load Description	LIN/Index	SUN	Load#	Qty	COR
------------------	-----------	-----	-------	-----	-----

Enter Serial Number, USA Number or Lot Number

UMODPC

612-301-03



Add a Load



- ① Highlight vehicle to add load to in Section 1 (D0023) and Press the [F9] key twice
 - Cursor moves to Section 3
- ② Select [F1] Add New Load
 - Vehicle load data screen appears, overlaying equipment list screen

F1-Add New Load F3-Next Load F4-Previous Load Press [F7]-Reassign Load			
F10-Copy Load to another Vehicle [ESC] to accept [CTRL-C] to abort			
DD/MM/YY		Vehicle Load Data	FICEUFO97
LIN	<input type="text"/>	LINIndex	<input type="text"/>
SUN	Load Number		Standard Indicator <input type="text"/> COR <input type="text"/>
Length	<input type="text"/>		Width <input type="text"/>
Height	<input type="text"/>		Weight <input type="text"/>
Quantity	<input type="text"/>	CuFt	<input type="text"/>
Total Weight	0		TotCuFt 0
Description	<input type="text"/>		
Type Equipment Code	<input type="text"/>	Type Pack Code	<input type="text"/>
Water Commodity Code	<input type="text"/>	Special Handling Code	<input type="text"/>
Type Cargo Code	<input type="text"/>	Ammo/Hazard	<input type="text"/>
Record 1 of 1			
LIN ITEM NO. (LIN): Press [F6] for Help			



Add a Load (Cont)



- ③ Type LIN number in LIN G40175 and press Enter
- ④ Type Index number 04 and press Enter
 - The cursor will move to the Standard Indicator field

F1-Add New Load F3-Next Load F4-Previous Load Press [F7]-Reassign Load

F10-Copy Load to another Vehicle [ESC] to accept [CTRL-C] to abort

DD/MM/YY

Vehicle Load Data

FICEUF097

LIN G40175 LINIndex 04 Model

SUN E0023 Load Number A Standard Indicator COR

Length Width

Height Weight

Quantity CuFt

Total Weight 0 TotCuFt 0

Description GENERATOR

Type Equipment Code Type Pack Code

Water Commodity Code Special Handling Code 9

Type Cargo Code Ammo/Hazard N

Record 1 of 1

LIN ITEM NO. (LIN): Press [F6] for Help

UMODPC

612-901-03



Add a Load (Cont)



- ⑤ To add a standard load, enter "Y" and the remaining data fields will be filled in
- Enter load quantity when prompted

F1-Add New Load F3-Next Load F4-Previous Load Press [F7]-Reassign Load

F10-Copy Load to another Vehicle [ESC] to accept [CTRL-C] to abort

DD/MM/YY

Vehicle Load Data

FICEUF097

LIN	G40175	LINIndex	04	Model	GENERATOR
SUN	E0023	Load Number	A	Standard Indicator	Y
				COR	
Length		62		Width	53
Height		27		Weight	548
Quantity		1		CuFt	1
Total Weight		548		TotCuFt	1

Description GENERATOR

Type Equipment Code	U	Type Pack Code	PC
Water Commodity Code	700	Special Handling Code	9
Type Cargo Code	Z	Ammo/Hazard	N

Record 1 of 1

LIN ITEM NO. (LIN): Press [F6] for Help

UMODPC

612-901-03



Add a Load (Cont)



- ⑥ To add a non-standard load, enter "N" and continue to fill in the remaining highlighted fields

F1-Add New Load F3-Next Load F4-Previous Load Press [F7]-Reassign Load

F10-Copy Load to another Vehicle [ESC] to accept [CTRL-C] to abort

DD/MM/YY

Vehicle Load Data

FICEUFO97

LIN	G40175	LINIndex	04	Model	
SUN	E0023	Load Number	A	Standard Indicator	N
				COR	
Length				Width	
Height				Weight	
Quantity				CuFt	
Total Weight			0	TotCuFt	0

Description GENERATOR

Type Equipment Code		Type Pack Code	
Water Commodity Code		Special Handling Code	
Type Cargo Code		Ammo/Hazard	

Record 1 of 1

LIN ITEM NO. (LIN): Press [F6] for Help

UMODPC

612-901-03



Add a Load (Cont)



- ⑦ When finished adding the load press Escape [Esc] and the load information will appear at the bottom of Equipment List screen



Nonstandard Loads



A nonstandard load may or may not have a
LIN number

- If load has been modified and no longer meets original specifications, i.e., (length x width x height or weight), enter the letter "N" in the Standard Indicator field and continue to fill in the remaining highlighted fields

F1-Add New Load F3-Next Load F4-Previous Load Press [F7]-Reassign Load

F10-Copy Load to another Vehicle [ESC] to accept [CTRL-C] to abort

DD/MM/YY

Vehicle Load Data

FICEUF097

LIN LINIndex Model

SUN Load Number Standard Indicator COR

Length Width

Height Weight

Quantity CuFt

Total Weight 0 TotCuFt 0

Description

Type Equipment Code Type Pack Code

Water Commodity Code Special Handling Code

Type Cargo Code Ammo/Hazard

Record 1 of 1

LIN ITEM NO. (LIN): Press [F6] for Help

UMODPC

612-901-03



Equipment Characteristics Query



- ❗ If you wish to query the database for the LIN number, from the Vehicle Load Data window, move the cursor to the LIN Field & press [F6]
 - The Equipment Characteristics Query window will appear, overlaying the Vehicle Load Data window

F1-Add New Load F2-Next Load F4-Previous Load Press [F7]-Reassign Load			
F10-Copy Load Vehicle [ESC] to accept [CTRL-C] to abort			
DD/MM/YY		Equipment Characteristics Query	
		FICEUF037	
Enter either LIN, Model, or Description. Enter Index if known or leave it blank			
LIN	Index	Model	Description
<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>
Press [ESC] to accept or [CTRL-C] to abort			
Enter valid LIN or use * or ? for pattern matching			
Record 1 of 1			
LIN ITEM NO. (LIN): Press [F6] for Help			
UMODPC			
612-901-03			



Equipment Characteristics Query (Cont)



- 2 Enter the LIN number, the Model or the Description in the proper field and the system will query its data base for the item information

TC-ACCIS will then display the equipment by LIN number showing the Model & Description



Equipment Characteristics Table



- If you don't know the LIN, model or description, then:
 - ❶ From the Equipment Characteristics Query window, enter an "*" or a "?" in the LIN/Index field. TC-ACCIS will display the entire Equipment Characteristics Table

Equipment Characteristics Table

F6 for more information on this LIN/Index (Length, Width, Height, etc.)

DD/MM/YY	Equipment Characteristics Table		FICEUF038
LIN/Index	Model	Description	Configuration
J49055 07	JHGV7.5A	GEN SET 7.5 KW WHLMTD	OPERATIONAL
J49055 08	JHGV7.5A	GEN SET 7.5 KW WHLMTD	RED-AR-220-10
J49055 09	JHGV7.5A	GEN SET 7.5 KW WHLMTD	CRATED
J49055 10	5982-1B	GEN SET 7.5 KW WHLMTD	OPERATIONAL
J49055 11	5982-1B	GEN SET 7.5 KW WHLMTD	RED-AR-220-10
J49055 12	5982-1B	GEN SET 7.5 KW WHLMTD	BOXED
J49055 04	POLMC111	GEN SET 7.5 KW WHLMTD	OPERATIONAL
J49055 05	POLMC111	GEN SET 7.5 KW WHLMTD	RED-AR-220-10

[CTRL-J] row down [CTRL-K] row up [F3] page down
Position cursor on a line and Press [ESC] Accept [CTRL-C] Abort



Equipment Characteristics Table (Cont)



- ② Select equipment from the Equipment Characteristics Table by scrolling to the item.
- ③ Then press [ESC] to accept & the system will return to the Vehicle Load Data screen
- ④ Enter the letter "Y" or "N" in the Standard Indicator field

F1-Add New Load F3-Next Load F4-Previous Load Press [F7]-Reassign Load

F10-Copy Load to another Vehicle [ESC] to accept [CTRL-C] to abort

DD/MM/YY

Vehicle Load Data

FICEUFO97

LIN J49055

LINIndex 04

Model POLMC111

SUN D0022

Load Number

Standard Indicator

Y-N

COR

Length

Width

Height

Weight

Quantity

CuFt

0

Total Weight

0

TotCuFt

Description

Type Equipment Code

Type Pack Code

Water Commodity Code

Special Handling Code

Type Cargo Code

Ammo/Hazard

Record 1 of 1

Enter LIN or Press F6 for Help

UMODPC

612-901-03



Equipment Characteristics Table (Cont)



- ④ If you enter the letter "Y" in the Standard Indicator field and press the Enter key the remaining fields will fill in with data

F1-Add New Load F3-Next Load F4-Previous Load Press [F7]-Reassign Load

F10-Copy Load to another Vehicle [ESC] to accept [CTRL-G] to abort

DD/MM/YY

Vehicle Load Data

FICEUFO97

LIN J49055

LINIndex 04

Model POLMG111

SUN D0022

Load Number

Standard Indicator

Y

COR

Length 78

Width 40

Height 39

Weight 825

Quantity 1

CuFt 71

Total Weight 825

TotCuFt 71

Description GEN SET 7.5 KW WHLMTD

Type Equipment Code 6

Type Pack Code PC

Water Commodity Code 700

Special Handling Code 9

Type Cargo Code Z

Ammo/Hazard N

Record 1 of 1
Enter LIN or Press F6 for Help

UMODPC

612-301-03



Equipment Characteristics Table (Cont)



- ⑤ If you enter the letter "N" in the Standard Indicator field and press the Enter Key you will be prompted to enter the remaining data
- ⑥ After entering the data, press [Esc] to accept your entries

F1-Add New Load F3-Next Load F4-Previous Load Press [F7]-Reassign Load

F10-Copy Load to another Vehicle [ESC] to accept [CTRL-C] to abort

DD/MM/YY

Vehicle Load Data

FICEUFO97

LIN J49055

LINIndex 04

Model POLMG111

SUN D0022

Load Number

Standard Indicator

N

COR

Length

Width

Height

Weight

Quantity

CuFt

0

Total Weight

0

TotCuFt

Description

Type Equipment Code

Type Pack Code

Water Commodity Code

Special Handling Code

Type Cargo Code

Ammo/Hazard

Record 1 of 1

Enter LIN or Press F6 for Help

UMODPC

612-301-03



Equipment Characteristics Table (Cont)



- After completing this selection, press [Esc].
- This brings you back to Section Three of the "Vehicle Load Data" screen. Press [F9] to return to the "Equipment List Data" then press [Esc]
- At the bottom of the screen the following question will appear

Have you completed processing equipment (y/n)?

EQUIPMENT: 1-Maintain 2-Copy 3-Sort 4-Query E-Exit

Press [ESC] to accept [F1] to add [F2] to delete or [F9] for detail section

DD/MM/YY

Equipment List Data

FICEUFO12

UIC WAD5A0

list sorted by

Exercise

* C	Sun	VI	Model	Description	LIN/Index	EchULN	D	M	S	A/H	*	
		D0022	V	M35A2	TRK CARGO 2-1/2-TON	X40009 02	00		D	K	Y	N *
		D0023	V	M35A2	TRK CARGO 2-1/2-TON	X4009 02	00		D	K	Y	N *
		D0024	V	M35A2	TRK CARGO 2-1/2-TON	J87150 02	00		D	K	Y	N *
		D0025	V	M35A2	TRK CARGO 2-1/2-TON	J87150 02	00		D	K	Y	N *
		D0026	V	M105A2	TRAILER CARGO 1-1/2	J87150 02	00		D	K	Y	N *

DETAIL FOR D0022

Ser#	3333	Bumper	TNG 23	Tra/Bmp#	/	Owner	
L	265	SqFt	177	Empty Wt	13180	TEC	WCC 867
W	96	CuFt	1193	ActWt	13745	STONS	6.9 SHC 4
H	81	CuLd	19	MaxWt	18180	MTONS	30 TCC I
Vehicle Remarks							

VEHICLE LOAD DATA FOR D0022

Load Description	LIN/Index	SUN	Load#	Qty	COR
GEN SET 7.5 KW WHLMTD	J49055 04	E0022	A	1	

Have you completed processing equipment (y/n)? ☐



Ammo/Hazardous Load



- The procedures for adding hazardous material loads are the same as for adding non-hazardous loads, with one exception.
 - The exception is the hazardous material record required upon completion of adding the load

EQUIPMENT: 1-Maintain 2-Copy 3-Sort 4-Query E-Exit

Press [ESC] to accept [F1] to add [F2] to delete or [F9] for detail section

DD/MM/YY

Equipment List Data

FICEUFO12

FULL list sorted by SHIPMENT NUMBER

UIC WAD5A0

Exercise D

* C	Sun	VI	Model	Description	LIN/Index	EchULN	D	M	S	A/H	*
			D0022 V M35A2	TRK CARGO 2-1/2-TON	X40009 02	00				D K Y N *	
			D0023 V M35A2	TRK CARGO 2-1/2-TON	X40009 02	00				D K Y N *	
			D0024 V M35A2	TRK CARGO 2-1/2-TON	J87150 02	00				D K Y N *	
			D0025 V M35A2	TRK CARGO 2-1/2-TON	J87150 02	00				D K Y N *	
			D0026 V M105A2	TRAILER CARGO 1-1/2	J87150 02	00				D K Y N *	

DETAIL FOR D0023

Ser#	3333	Bumper	TNG	23	Tra/Bmp#	/	Owner
L	285	SqFt	177	Empty Wt	13180	TEC	WCC 867 VM TPC vo
W	96	CuFt	1193	ActWt	13180	STONS	8.6 SHC 9 CCCI R2DB Ov N
H	81	CuLd	1	MaxWt	18180	MTONS	30 TCC z

Vehicle Remarks

VEHICLE LOAD DATA FOR D0023

Load Description	LIN/Index	SUN	Load#	Qty	COR

UMODPC

612-901-03

F1-Add New Load F3-Next Load F4-Previous Load Press [F7]-Reassign Load

F10-Copy Load to another Vehicle [ESC] to accept [CTRL-C] to abort

DD/MM/YY

Vehicle Load Data

FICEUF097

LIN	YA0074	LINIndex	01	Model	500 LBS
SUN	E0022	Load Number	A	Standard Indicator	Y
				COR	
Length		40.0		Width	48.0
Height		17.0		Weight	565
Quantity		1		CuFt	19
Total Weight		565		TotCuFt	19
Description	AMMO .60 CAL & BELOW				
Type Equipment Code		R		Type Pack Code	PC
Water Commodity Code		680		Special Handling Code	1
Type Cargo Code		1		Ammo/Hazard	Y

Record 1 of 1

LIN ITEM NO. (LIN): Press [F6] for Help

UMODPC

612-901-03



Ammo/Hazardous Load (Cont)



- After loading the hazardous material, press [Esc] to accept the load. The load appears in Section Three of the screen.
- Next press [F9] and the cursor moves to Section One
 - The truck is highlighted and a "Y" is displayed in the "A/H" field indicating there is ammunition or hazardous materials in the load

EQUIPMENT: 1-Maintain 2-Copy 3-Sort 4-Query E-Exit

Press [Esc] to accept [F1] to add [F2] to delete or [F9] for detail section

DD/MM/YY Equipment List Data FICEUFO12

FULL list sorted by SHIPMENT NUMBER

UIC WAD5A0 Exercise D

* C	Sun	VI	Model	Description	LIN/Index	EchULN	D	M	S	A/H	*
			D0022 V M35A2	TRK CARGO 2-1/2-TON	X40009 02	00				D K Y N *	
			D0023 V M35A2	TRK CARGO 2-1/2-TON	X40009 02	00				D K Y Y *	
			D0024 V M35A2	TRK CARGO 2-1/2-TON	J87150 02	00				D K Y N *	
			D0025 V M35A2	TRK CARGO 2-1/2-TON	J87150 02	00				D K Y N *	
			D0026 V M105A2	TRAILER CARGO 1-1/2	J87150 02	00				D K Y N *	

DETAIL FOR D0023

Ser# 3333 Bumper TNG 23 Tra/Bmp# / Owner

L 285 SqFt 177 Empty Wt 13180 TEC WOC 867 VI TPC vo

W 96 CuFt 1193 ActWt 13180 STONS 8.6 SHC 9 CCCI R2DB Ov N

H 81 CuLd 1 MaxWt 18180 MTONS 30 TCC z

Vehicle Remarks

VEHICLE LOAD DATA FOR D0023

Load Description	LIN/Index	SUN	Load#	Qty	COR
AMMO .60CAL & BELOW	Y100074 01	D0023	A	1	

UMODPC 612-301-03



Ammo/Hazardous Load (cont)



- Return to the Equipment Ring Menu by pressing [Esc]
- A message will appear stating:

"Have you completed processing equipment (y/n)?"

EQUIPMENT: 1-Maintain 2-Copy 3-Sort 4-Query E-Exit

Press [ESC] to accept [F1] to add [F2] to delete or [F9] for detail section

DD/MM/YY

Equipment List Data

FICEUFO12

UIC WAD5A0

list sorted by

Exercise

* C	Sun	VI	Model	Description	LIN/Index	EchULN	D	M	S	A/H	*				
			D0022	V	M35A2	TRK CARGO 2-1/2-TON	X40009	02	00		D	K	Y	N	*
			D0023	V	M35A2	TRK CARGO 2-1/2-TON	X4009	02	00		D	K	Y	N	*
			D0024	V	M35A2	TRK CARGO 2-1/2-TON	J87150	02	00		D	K	Y	N	*
			D0025	V	M35A2	TRK CARGO 2-1/2-TON	J87150	02	00		D	K	Y	N	*
			D0026	V	M105A2	TRAILER CARGO 1-1/2	J87150	02	00		D	K	Y	N	*

DETAIL FOR D0022

Ser#	3333	Bumper	TNG	23	Tra/Bmp#	/	Owner
L	265	SqFt	177	Empty Wt	13180	TEC	WCC 867
W	96	CuFt	1193	ActWt	13745	STONS	6.9 SHC 4
H	81	CuLd	19	MaxWt	18180	MTONS	30 TCC I
Vehicle Remarks							

VEHICLE LOAD DATA FOR D0022

Load Description	LIN/Index	SUN	Load#	Qty	COR
AMMO .60CAL & BELOW	YA0074 01	D0022	A	1	

Have you completed processing equipment (y/n)?

☐



Ammo/Hazardous Load (Cont)



- After pressing "y" you are taken back to the main Equipment Ring Menu
- Press [E] to exit or highlight "E-Exit" and press enter to exit.
- A message will appear at the bottom of screen stating:

"Do you want to update hazardous materials records? (y/n)"

EQUIPMENT: 1-Maintain 2-Copy 3-Sort 4-Query E-Exit

Exit to previous menu

DD/MM/YY

Equipment List Data
list sorted by

FICEUFO12

UIC

Exercise

* C Sun VI Model Description

LIN/Index

EchULN DMS A/H *

DETAIL FOR

Ser#

Bumper

Owner

L

SqFt

Empty Wt

TEC

WCC

WI

TPC

W

CuFt

ActWt

STONS

SHC

CCCI

Ov

H

CuLd

MaxWt

MTONS

TCC

Vehicle Remarks

Do you want to update the Hazardous materials records (y/n)?

UMODPC

612-901-03



Ammo/Hazardous Load (Cont)



- By entering "y" you will be prompted by additional screens to process each of the ammo/ hazardous material loads you have entered.
- When this process is completed you will then go back to the Maintain Ring Menu



Maintaining Special Handling Equipment (F Records) & Creating DEL



Maintaining Special Handling Equipment (F Records)



- Special Handling Equipment is a unit's TO&E equipment other than vehicles or secondary loads (F records). This equipment must be identified by Echelon/ULN for movement to POE.

MAINTAIN: 1-Header 2-Vehicle 3- SpecHdlng 4-Actual Weight...

Maintain Vehicle Entries on Equipment List

DD/MM/YY Equipment List Data FICEUFO12
list sorted by

UIC Exercise
* C Sun VI Model Description LIN/Index EchULN DMS A/H *

DETAIL FOR
Ser# Bumper Owner
L SqFt Empty Wt TEC WCC WI TPC
W CuFt ActWt STONS SHC CCCI Ov
H CuLd MaxWt MTONS TCC

Vehicle Remarks



Maintaining Special Handling Equipment (F Records) (Cont)



- Select option "3-Spec Hdling" (special handling) from the Maintain ring menu



Maintaining Special Handling Equipment (F Records) (Cont)



- Select option "1-Maintain" from the Equipment Ring Menu
- Special Handling screens are maintained the same as Vehicle data screens

EQUIPMENT: 1-Maintain 2-Copy 3-Sort 4-Query E-Exit

Press [ESC] to accept [F1] to add [F2] to delete or [F9] for detail section

DD/MM/YY Equipment List Data FICEUFO12

-----FULL list sorted by SHIPMENT NUMBER-----

UIC	WAD5A0	Exercise	D
* C Sun	Model	Description	LIN/Index EchULN D M S A/H *
F0003	NONE	463-L AF LONG PALLET	YA0081 01 00 R F Y N *
F0004	NONE	463-L AF LONG PALLET	YA0081 01 00 R F Y N *
F0005	NONE	463-L AF LONG PALLET	YA0081 01 00 R F Y N *

-----DETAIL FOR F0003-----

Ser#	D-WAD5A0-F0003	Bumper	N.O.H.	Owner
L	108 SqFt	66	Empty Wt	350 TEC WCC 700 Wl TPC PC
W	88 CuFt	22	ActWt	8375 STONS 4.1 SHC 9 CCCI J3BA Ov N
H	4 CuLd	17	MaxWt	10100 MTONS 1 TCC Z

Vehicle Remarks

-----VEHICLE LOAD DATA FOR F0003-----

Load Description	LINIndex	SUN	Load#	Qty	COR
YELLOW TAT BAGGAGE		G0003	A	1	

LIN/Index: Press [F6] for Help

UMODPC

612-301-03



Maintaining Special Handling Equipment (F Records) (Cont)



- Note: Adding Special Handling Equipment follow the same procedures as entering Vehicle Data



TIME: 06:00		(PERCENT FROM)										DATE: 06/01/00	
TIME: 06:00		AUEL REPORT-UNIT/QUANTITY LIST										DATE: 06/01/00	
TIME: 06:00		UNIT NAME: RTH TRANS CO										DATE: 06/01/00	
TIME: 06:00		STATION: FTEUSTS										DATE: 06/01/00	
TIME: 06:00		STATE: LA										DATE: 06/01/00	
SHIPMENT #		SHIPMENT UNIT		DIMENSIONS		PLANNED ACTUAL		PLANNED ACTUAL		PLANNED ACTUAL		PLANNED ACTUAL	
NUMBER N LIN		IND DESCRIPTION		METER #		WTHM HGTG LTH		ITEM WTLES		ITEM WTLES		ITEM WTLES	
D0005 1 1000		TRUCK TRUCK 0005 1000		H302A 1 1000		1000 1000 1000		1000 1000		1000 1000		1000 1000	
D0005 1 1000		TRUCK TRUCK 0005 1000		H302A 1 1000		1000 1000 1000		1000 1000		1000 1000		1000 1000	
D0005 1 1000		TRUCK TRUCK 0005 1000		H302A 1 1000		1000 1000 1000		1000 1000		1000 1000		1000 1000	
D0005 1 1000		TRUCK TRUCK 0005 1000		H302A 1 1000		1000 1000 1000		1000 1000		1000 1000		1000 1000	
D0005 1 1000		TRUCK TRUCK 0005 1000		H302A 1 1000		1000 1000 1000		1000 1000		1000 1000		1000 1000	
D0005 1 1000		TRUCK TRUCK 0005 1000		H302A 1 1000		1000 1000 1000		1000 1000		1000 1000		1000 1000	
D0005 1 1000		TRUCK TRUCK 0005 1000		H302A 1 1000		1000 1000 1000		1000 1000		1000 1000		1000 1000	
D0005 1 1000		TRUCK TRUCK 0005 1000		H302A 1 1000		1000 1000 1000		1000 1000		1000 1000		1000 1000	
D0005 1 1000		TRUCK TRUCK 0005 1000		H302A 1 1000		1000 1000 1000		1000 1000		1000 1000		1000 1000	
D0005 1 1000		TRUCK TRUCK 0005 1000		H302A 1 1000		1000 1000 1000		1000 1000		1000 1000		1000 1000	
D0005 1 1000		TRUCK TRUCK 0005 1000		H302A 1 1000		1000 1000 1000		1000 1000		1000 1000		1000 1000	
D0005 1 1000		TRUCK TRUCK 0005 1000		H302A 1 1000		1000 1000 1000		1000 1000		1000 1000		1000 1000	
D0005 1 1000		TRUCK TRUCK 0005 1000		H302A 1 1000		1000 1000 1000		1000 1000		1000 1000		1000 1000	
D0005 1 1000		TRUCK TRUCK 0005 1000		H302A 1 1000		1000 1000 1000		1000 1000		1000 1000		1000 1000	
D0005 1 1000		TRUCK TRUCK 0005 1000		H302A 1 1000		1000 1000 1000		1000 1000		1000 1000		1000 1000	
D0005 1 1000		TRUCK TRUCK 0005 1000		H302A 1 1000		1000 1000 1000		1000 1000		1000 1000		1000 1000	
D0005 1 1000		TRUCK TRUCK 0005 1000		H302A 1 1000		1000 1000 1000		1000 1000		1000 1000		1000 1000	
D0005 1 1000		TRUCK TRUCK 0005 1000		H302A 1 1000		1000 1000 1000		1000 1000		1000 1000		1000 1000	
D0005 1 1000		TRUCK TRUCK 0005 1000		H302A 1 1000		1000 1000 1000		1000 1000		1000 1000		1000 1000	
D0005 1 1000		TRUCK TRUCK 0005 1000		H302A 1 1000		1000 1000 1000		1000 1000		1000 1000		1000 1000	
D0005 1 1000		TRUCK TRUCK 0005 1000		H302A 1 1000		1000 1000 1000		1000 1000		1000 1000		1000 1000	
D0005 1 1000		TRUCK TRUCK 0005 1000		H302A 1 1000		1000 1000 1000		1000 1000		1000 1000		1000 1000	
D0005 1 1000		TRUCK TRUCK 0005 1000		H302A 1 1000		1000 1000 1000		1000 1000		1000 1000		1000 1000	
D0005 1 1000		TRUCK TRUCK 0005 1000		H302A 1 1000		1000 1000 1000		1000 1000		1000 1000		1000 1000	
D000													

- Two digit code in "TYPE DATA:" block indicates that this is a DEL report

UMODPC

612-301-03



Create the Deployment Equipment List (DEL)



- When a unit deploys, the UMO must create a Deployment Equipment List (DEL) by copying the equipment from the AUDEL into the DEL
- The UMO will receive a 2-character TDC from the UMC for the deployment/exercise based on FORSCOM direction
- The AUDEL must already be updated and accurate

Press [F2] to cancel insert

DD/MM/YY

Unit Header Detail

FICEUF007

Exercise X4 - FT STOCKTON DEFAULT UIC WWWWWW - Default Corps

Description Default Exercise-Peacetime TDC for reporting Unit Movement
Data to the FORSCOM COMPASS System

Ech/U/LN	Description	Str	SC	Avail Date	Dpt Date	Rqd Date	DMOD
<input type="text"/>		<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>

Remarks

Enter/Update Echelon (Press [F6] for help)

UMODPC

612-301-03



Create the DEL (Cont)



- A header must be created to process a Deployment Equipment List. The Unit Header contains the following:
 - Echelon identifier
 - Echelon description field
 - "Str" field is number of personnel deploying
 - SC field, number of Super Cargoes/Security
 - Available Date is date of the movement
 - RDD is date unit will actually be on site

Equipment List Data FICEUFO02

The Type Data Code you chose to maintain currently has no data. If you wish to create an Equipment List for this Type Data Code you may do so by:

(2-Partial Copy)-manually selecting equipment from another TDC or

(3-Manual Entry)-by manually entering equipment